



Package Contents:

- (1) CMPTRI – Flexible Mini 7.5" Tripod
- (1) CAM-POUCH - Carrying Bag


Device Compatibility:

Small digital cameras with the standard 1/4"-20 camera pattern, including the Sony Action Cam, Sony POV HD Flash Memory Camcorder, Contour ROAM2, JVC ADIXXION, Samsung NX2000 and Samsung NX300, Olympus OM-D E-M1, E-M5, E-M10, Fujifilm X100T, Nikon Coolpix S9700, Panasonic Lumix DMC-FZ70, Canon PowerShot S120, SX50, PowerShot G16 X Mk II.


1 Attach camera by screwing it onto the 1/4"-20 mounting bolt.




2 Loosen the adjustment knob to change position. Retighten to set.



Achieve unique camera angles by attaching the mount to any object the bendable legs can securely wrap around.



Release the 1/4"-20 mount by unscrewing lateral screw and pressing on release tab.



! Safety Precautions

Arkon is not responsible for any damages caused to your device or yourself due to the installation or use of the mount.

ARKON
RESOURCES INC.

The Mobile Mounting Specialists™

Consumer Hotline:

USA (800) 841-0884

INT'L (626) 254-9005

Monday - Friday 9 am - 5 pm, PST

www.arkon.com

Arcadia, CA 91006 USA

Designed in USA | Made in China

© Copyright 2014 Arkon Resources, Inc.