




Included Components:

- A. 3x LockVise™ Locking Tablet Holder with Hardware Kit (TAB005KL)
- B. 1x XMS 20mm AMPS Adapter (AP20MMAL)
- C. 1x Weighted Base (SPHD8BASE)
- D. 1x Remarkable Creator™ Pole (SPHD8L29)
- E. 1x Clamp Base (SPHD8L29CLAMP)
- F. 2x Clamp Base with 22mm Ball (GN03122)
- G. 2x 22mm Swivel Tightening Ring (SP-SB-RING-22)
- H. 2x 4-Hole AMPS to 22mm Ball Adapter (SP-SB-AMPS-22)

Tablet Compatibility

4.11" - 7.88"	Wide
7.44" - 11.87"	Height

Important: Clean the application surface and make sure it is free of dirt, dust, and grease before installation.


If you need a replacement part, please refer to the SKU options below:

- Rubber Cover for the Clamp: SPCLAMPVCVR

Based on your preferred base, please follow the steps outlined below.


1 Install the Pole in the Base

Place the pole in the base by utilizing the alley key included with the base and turn it clockwise to secure it in place.




2 Attaching the Adapter to the Pole

Insert the 20mm ball adapter pole by loosening the knob and then retightening for a secure fit.




1 Align and Adjust the Clamp Width

Position the clamp on the edge of the surface where you want to mount the system. The multi-hole design allows compatibility with a wide range of surfaces and setups.



2 Secure the Clamp

Rotate the adjustment knob to open the clamp. Tighten the adjustment knob until the clamp is firmly secured to the surface. The durable clamp mechanism ensures your setup stays stable.



WARNING

CHOKING HAZARD - Keep out of reach from children under 8 yrs. as they can choke or suffocate on parts included with this system

WARNING

Arkon® is not responsible for any damages caused to your device or yourself due to the installation or use of this mount. Do not install Arkon® products near areas that interfere with operation of vehicles. Arkon® assumes no responsibility or liability for injury or death as a result of failure to install in a safe location. Arkon® is not responsible for any damages caused to vehicles, product, or people due to the installation or use of this product.


Continued on page 2



Based on your preferred base, please follow the steps outlined below.


3 Adjust the Height of the Mount

To modify the height and angle of the mount, simply loosen the ring and knob. Once you've achieved the desired position, retighten them to secure it in place.




4 AMPS Adapter Installation

Locate the AMPS mounting pattern on the back of the holder. Align the AMPS adapter with the holes, insert the included screws, and tighten them until the adapter is securely attached.




3 Install the Pole in the Clamp Base

Place the pole in the clamp base by utilizing the alley key included with the weighted base and turn it clockwise to secure it in place.



4 Attaching and Adjusting the Adapter on the Pole

Loosen the knob to insert the 20mm ball adapter onto the pole, then retighten for a secure fit. To adjust the height and angle of the mount, loosen the ring and knob, position it as desired, and retighten to lock it in place.



WARNING

CHOKING HAZARD - Keep out of reach from children under 8 yrs. as they can choke or suffocate on parts included with this system

WARNING


Arkon® is not responsible for any damages caused to your device or yourself due to the installation or use of this mount. Do not install Arkon® products near areas that interfere with operation of vehicles. Arkon® assumes no responsibility or liability for injury or death as a result of failure to install in a safe location. Arkon® is not responsible for any damages caused to vehicles, product, or people due to the installation or use of this product.

Continued on page 3




5 Attach the Adapters to the Clamps

Position the tightening ring over the 22mm ball on the clamp mount. Insert the AMPS adapter into the clamp mount. Secure the connection by tightening the ring in place.




6 AMPS Adapter Installation

Locate the AMPS mounting pattern on the back of the holder. Align the AMPS adapter with the holes, insert the included screws, and tighten them until the adapter is securely attached.



7 Installing the Clamp Mount onto the Full Assembly

Turn the knob counterclockwise to loosen the clamp. Slide it onto the pole at your desired position, then turn the knob clockwise to securely tighten it in place.



WARNING

CHOKING HAZARD - Keep out of reach from children under 8 yrs. as they can choke or suffocate on parts included with this system

WARNING

Arkon® is not responsible for any damages caused to your device or yourself due to the installation or use of this mount. Do not install Arkon® products near areas that interfere with operation of vehicles. Arkon® assumes no responsibility or liability for injury or death as a result of failure to install in a safe location. Arkon® is not responsible for any damages caused to vehicles, product, or people due to the installation or use of this product.


Continued on page 4



Tablet Holder Installation Steps:


8 Adjusting the Length of the Tablet Holder

Use a Phillips screwdriver to loosen the adjustment screws. This will allow you to expand the width and depth of the holder to fit your device. Once adjusted, retighten the screws to secure the holder in place.




9 Installing the Tablet into the Holder

Insert the locking keys to release the height adjustment. Pull upward on the top arm to expand the holder, creating enough space to fit your tablet securely.




10 Locking the Tablet into the Holder

Place the tablet into the holder and adjust the top arm to fit snugly. Once the tablet is properly positioned, press the button on the back of the holder to lock it securely.



11 Optional – Installing Foam Padding

If you're not using a tablet case, locate the included foam padding from the packaging. Place the padding in the center of the holder to provide a secure and cushioned fit for your device.



WARNING

CHOKING HAZARD - Keep out of reach from children under 8 yrs. as they can choke or suffocate on parts included with this system

WARNING

Arkon® is not responsible for any damages caused to your device or yourself due to the installation or use of this mount. Do not install Arkon® products near areas that interfere with operation of vehicles. Arkon® assumes no responsibility or liability for injury or death as a result of failure to install in a safe location. Arkon® is not responsible for any damages caused to vehicles, product, or people due to the installation or use of this product.

