

Included Components:


- A. 1x LockVise™ Locking Tablet Holder with Hardware Kit (TAB005KL)
- B. 1x Clamp Pedestal with 4" Arm and AMPS Adapter (APMAMPS25MM)
- C. 1x OCTO™ Series 25mm Ball with Button Socket (SPRM8SKT)
- D. 1x OCTO™ Series Button to 4-Hole AMPS Adapter (SPRM8CBAMPS)

Tablet Compatibility


4.11" - 7.88"	Wide
7.44" - 11.87"	Height

**Important:** Clean the application surface and make sure it is free of dirt, dust, and grease before installation.


- 1
- Install the AMPS Adapter Plate to the Holder**  
Align the AMPS 4-hole adapter with the mounting holes on the back of the holder. Insert the four screws through the adapter plate and into the holder, then tighten securely to ensure a firm connection.



- 2
- Connect the Ball and Button Pattern Ends**  
Rotate the knob counterclockwise to loosen them. Attach the 25mm ball to one end and the button pattern to the opposite end of the assembly. Once both are properly aligned, turn the knob clockwise to tighten and securely lock the components in place.



- 3
- Mount Installation**  
Position the pedestal on the desired mounting surface. Using appropriate hardware (**not included**), securely fasten the pedestal to ensure a stable and reliable installation.



**WARNING**  
CHOKING HAZARD - Keep out of reach from children under 8 yrs. as they can choke or suffocate on parts included with this system

**WARNING**  
Arkon® is not responsible for any damages caused to your device or yourself due to the installation or use of this mount. Do not install Arkon® products near areas that interfere with operation of vehicles. Arkon® assumes no responsibility or liability for injury or death as a result of failure to install in a safe location. Arkon® is not responsible for any damages caused to vehicles, product, or people due to the installation or use of this product.


Continued on page 2



## Tablet Holder Installation Steps:


### 4 Adjusting the Length of the Tablet Holder

Use a Phillips screwdriver to loosen the adjustment screws. This will allow you to expand the width and depth of the holder to fit your device. Once adjusted, retighten the screws to secure the holder in place.




### 5 Installing the Tablet into the Holder

Insert the locking keys to release the height adjustment. Pull upward on the top arm to expand the holder, creating enough space to fit your tablet securely.




### 6 Locking the Tablet into the Holder

Place the tablet into the holder and adjust the top arm to fit snugly. Once the tablet is properly positioned, press the button on the back of the holder to lock it securely.



### 7 Optional – Installing Foam Padding

If you're not using a tablet case, locate the included foam padding from the packaging. Place the padding in the center of the holder to provide a secure and cushioned fit for your device.



#### WARNING

CHOKING HAZARD - Keep out of reach from children under 8 yrs. as they can choke or suffocate on parts included with this system

#### WARNING

Arkon® is not responsible for any damages caused to your device or yourself due to the installation or use of this mount. Do not install Arkon® products near areas that interfere with operation of vehicles. Arkon® assumes no responsibility or liability for injury or death as a result of failure to install in a safe location. Arkon® is not responsible for any damages caused to vehicles, product, or people due to the installation or use of this product.

