

Includes:

- 1 - Slim-Grip® Ultra Pro Tablet Holder with Support Legs (TAB006XL)
- 1 - Dual T-Tab with 22mm ball adapter (SP-SB-2T-22)
- 1 - Tightening Ring 22mm compatible (SP-SB-RING-22)
- 1 - Clamp with 22mm ball (GN03122)

Important: Clean the application surface and make sure it is free of dirt, dust, and grease before installation.

Leg Selection Guide


Choose the appropriate legs based on your tablet size, with or without a case:

- Tablets (**approximately 6.37" to 8.81"**) - Use 2 small legs.
- Tablets (**approximately 7.12" to 9.25"**) - Use 1 long leg and 1 small leg.
- Tablets (**approximately 7.62" to 10"**) - Use 2 long legs.
- Tablets (**approximately 8.75" to 11.12"**) - Use 1 long leg and 1 extra long leg.

1

Attach the Components


Position the tightening ring over the 22mm ball on the clamp mount. Insert the Dual-T adapter into the clamp mount. Secure the connection by tightening the ring in place.



2

Install the Dual T-Tab adapter into the tablet holder


Insert the Dual-T adapter into the slot located behind the holder. Then, slide the adapter upwards to ensure it is securely in place.



3

Adjusting the Clamp Mount

To widen the clamp arms to the desired width, turn the knob counterclockwise. Attach to your desired surface and then tighten the knob clockwise to secure in place.



WARNING

CHOKING HAZARD - Keep out of reach from children under 8 yrs. as they can choke or suffocate on parts included with this system

WARNING

Arkon® is not responsible for any damages caused to your device or yourself due to the installation or use of this mount. Do not install Arkon® products near areas that interfere with operation of vehicles. Arkon® assumes no responsibility or liability for injury or death as a result of failure to install in a safe location. Arkon® is not responsible for any damages caused to vehicles, product, or people due to the installation or use of this product.


Continued on page 2



4

Installing the legs to the holder


Install the support legs required based on the recommendations listed above. Slide the support legs into the holder's support leg channels.



5

Extend the spring-loaded mechanism

To extend the legs, insert one end of the tablet into the bottom support legs.



6

Install the tablet


With the holder's spring-loaded support legs expanded, lay the tablet flat on the holder.



7

Release the tablet to secure

Gently release the tablet into the holder, allowing the bottom spring-loaded support legs to secure the tablet.



WARNING

CHOKING HAZARD - Keep out of reach from children under 8 yrs. as they can choke or suffocate on parts included with this system

WARNING

Arkon® is not responsible for any damages caused to your device or yourself due to the installation or use of this mount. Do not install Arkon® products near areas that interfere with operation of vehicles. Arkon® assumes no responsibility or liability for injury or death as a result of failure to install in a safe location. Arkon® is not responsible for any damages caused to vehicles, product, or people due to the installation or use of this product.

